

KLINGER[®]KGS

Installation instructions





KLINGER[®]KGS

The following instructions have to be observed so that a reliable sealing connection can be ensured.

1. Gasket selection

The suitable material quality can be selected from the KLINGER[®] information sheet – above all, from the resistance chart.

2. Flanges

Flanges should be parallel, metallic, clean and dry, the gasket has to be mounted centrically. Please ensure the correct gasket dimensions.

The gasket should never tower into the throughhole (media flow)!

The outer diameter of the KLINGER®KGS gasket is adapted to the bolt circle of the flange. Therefore safe centering at the screws is ensured.

3. Installation

The installation of the gaskets should be carried out without using any grease or oil containing separating/sealing agents or similar.

In no case, oil or grease containing products may be used, because they have a negative influence on the safety of the whole flange connection.

5. Retightening

"Retightening" is not required if these instructions are followed.

6. Multiple use

■ For reasons of safety, the multiple use of gaskets is generally not recommended.

4. Screws

When installing the screws, they have to be tightened evenly in two to three steps crosswise.

The screws should be lubricated. Pay attention to the tightening torques.

On request, please make use of advice of the KLINGER

KLINGER offers you excellent sealing products for all fields of application


KLINGER®KGS





KLINGER®KGS-Flon





KLINGER®KGS/VD

KLINGER®KNS



KLINGER Denmark A/S | Nyager 12-14 | DK-2605 Broendby | T +45 43 64 66 11 | www.klinger.dk

Certified according to DIN EN ISO 9001:2008

Subject to technical changes. No responsibility is accepted for the accuracy of this information. Status: November 2016

BLUE COMPETENCE Alliance Member Partner der Nachhaltigkeitsinitiative des Maschinen- und Anlagenbaus

